



# WALL AIR HANDLER DUCTLESS SPLIT SYSTEM

**Installation Manual** 

#### **MODELS**

DHWAL09DA 9 k DHWAL12DA 12 k DHWAL18DA 18 k DHWAL24DA 24 k






### **Table of Contents**

### Installation Manual

0	Safety Precautions	3
1	Accessories	.5
2	Installation Summary - Indoor Unit	. 7
3	Unit Parts	9



4	Indoor Unit Installation	10
	1.Select installation location	10
	2.Attach mounting plate to wall	11
	3.Drill wall hole for connective piping	11
	4.Prepare refrigerant piping	13
	5.Connect drain hose	14
	6.Connect signal cable	16
	7. Wrap piping and cables	17
	8.Mount indoor unit	17

- 10 Disposal Guidelines......20
- 11 Specifications and Performance......21

### **Safety Precautions**

#### **Read Safety Precautions Before Installation**

Incorrect installation due to ignoring instructions can cause serious damage or injury. The seriousness of potential damage or injuries is classified as either a WARNING or CAUTION.



This is a safety alert symbol. It is used to alert you to potential physical injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.



#### **WARNING**

- **Do not** modify the length of the power supply cord or use an extension cord to power the unit. **Do not** share the electrical outlet with other appliances. Improper or insufficient power supply can cause fire or electrical shock.
- When connecting refrigerant piping, **do not** let substances or gases other than the specified refrigerant enter the unit. The presence of other gases or substances will lower the unit's capacity, and can cause abnormally high pressure in the refrigeration cycle. **This can cause explosion and injury.**
- **<u>Do not</u>** allow children to play with the air conditioner. Children must be supervised around the unit at all times.
- 1. Installation shall be performed by an authorized dealer or specialist. Defective installation can cause water leakage, electrical shock, or fire.
- Installation shallbe performed according to the installation instructions. Improper installation can cause water leakage, electrical shock, or fire.
   (In North America, installation must be performed in accordance with the requirement of NEC and CEC by authorized personnel only.)
- 3. Contact an authorized service technician for repair or maintenance of this unit.
- 4. Only use the included accessories, parts, and specified parts for installation. Using non-standard parts can cause water leakage, electrical shock, fire, and can cause the unit to fail.
- 5. Install the unit in a firm location that can support the unit's weight. If the chosen location cannot support the unit's weight, or the installation is not done properly, the unit may drop and cause serious injury and damage.

### **♠** w

#### WARNING

- 6. For all electrical work, follow all local and national wiring standards, regulations, and the Installation Manual. You must use an independent circuit and single outlet to supply power. Do not connect other appliances to the same outlet. Insufficient electrical capacity or defects in electrical work can cause electrical shock or fire.
- 7. For all electrical work, use the specified cables. Connect cables tightly, and clamp them securely to prevent external forces from damaging the terminal. Improper electrical connections can overheat and cause fire, and may also cause shock.
- 8. All wiring must be properly arranged to ensure that the control board cover can close properly. If the control board cover is not closed properly, it can lead to corrosion and cause the connection points on the terminal to heat up, catch fire, or cause electrical shock.
- 9. In certain functional environments, such as kitchens, server rooms, etc., the use of specially designed air-conditioning units is highly recommended.
- 10. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- 11. This appliance should be used with supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.



#### **WARNING**

- For units that have an auxiliary electric heater, **do not** install the unit within 3 feet (1 meter) of any combustible materials.
- **<u>Do not</u>** install the unit in a location that may be exposed to combustible gas leaks. If combustible gas accumulates around the unit, it may cause fire.
- **<u>Do not</u>** operate your air conditioner in a wet room such as a bathroom or laundry room. Too much exposure to water can cause electrical components to short circuit.
- 1. The product must be properly grounded at the time of installation, or electrical shock may occur.
- 2. Install drainage piping according to the instructions in this manual. Improper drainage may cause water damage to your home and property.

#### **Note about Fluorinated Gasses**

- 1. This air-conditioning unit contains fluorinated gasses. For specific information on the type of gas and the amount, please refer to the relevant label on the unit itself.
- 2. Installation, service, maintenance and repair of this unit must be performed by a certified technician.
- 3. Product removal and recycling must be performed by a certified technician.
- 4. If the system has a leak-detection system installed, it must be checked for leaks at least every 12 months.


Accessories

The air conditioning system comes with the following accessories. Use all of the installation parts and accessories to install the air conditioner. Improper installation may result in water leakage, electrical shock and fire, or cause the equipment to fail.

Name	Shape	C	Quantity	
Mounting plate		1		
Clip anchor		5		
Mounting plate fixing screw ST3.9 X 25	411111111	5		
Remote controller		1		
Fixing screw for remote controller holder ST2.9 x 10		2	Optional	
Remote controller holder		1	Parts	
Dry battery AAA.LR03		2		
Seal		1 (for cooling & heating - models only)		
Drain joint				


Name	PIPE SIZE		Quantity
	Liquid side	Ф1/4 in (6.35mm)	
Connecting pipe assembly		Ф3/8 in (9.52mm)	Parts you must purchase.
assembly	Gas side	Ф3/8 in (9.52mm)	Consult the dealer about
		Φ1/2 in (12.7mm)	the pipe size.
		Ф5/8 in (16mm)	
		Φ3/4 in (19mm)	

# **Installation Summary - Indoor Unit**




Select Installation Location (Page 11)


Determine Wall Hole Position (Page 12)



Attach Mounting Plate (Page 12)



Drill Wall Hole (Page 12)



### **Unit Parts**

3

**NOTE:** The installation must be performed in accordance with the requirements of local and national standards.





Fig. 2.1

- 1. Wall Mounting Plate
- 2. Front Panel
- 3. Power Cable (Field Source)
- 4. Louver
- 5. Functional Filter (On Front of Main Filter Some Units)
- 6. Drainage Pipe
- 7. Signal Cable (Field Source)
- 8. Refrigerant Piping
- 9. Remote Controller
- 10. Remote controller Holder
- Outdoor Unit Power Cable (Field Source)

Illustrations in this manual are for explanatory purposes. The actual shape of your indoor unit may be slightly different. The actual shape shall prevail.

### **Indoor Unit Installation**





# Installation Instructions – Indoor Unit

#### PRIOR TO INSTALLATION

Before installing the indoor unit, refer to the label on the product box to make sure that the model number of the indoor unit matches the model number of the outdoor unit.

#### **Step 1: Select installation location**

Before installing the indoor unit, you must choose an appropriate location. The following are standards that will help you choose an appropriate location for the unit.

# Proper installation locations meet the following standards:

☑Good air circulation

**☑**Convenient drainage

☑Noise from the unit will not disturb other people

☑Firm and solid—the location will not vibrate

☑Strong enough to support the weight of the unit

☐ A location at least **40in**. (one meter) from all other electrical devices (e.g., TV, radio, computer)

# <u>DO NOT</u> install unit in the following locations:

- Near any source of heat, steam, or combustible gas
- Near flammable items such as curtains or clothing
- Near any obstacle that might block air circulation
- Near the doorway
- In a location subject to direct sunlight

#### **NOTE ABOUT WALL HOLE:**

If there is no fixed refrigerant piping:

While choosing a location, be aware that you should leave ample room for a wall hole (see **Drill wall hole for connective piping** step) for the signal cable and refrigerant piping that connect the indoor and outdoor units. The default position for all piping is the right side of the indoor unit (while facing the unit). However, the unit can accommodate piping to both the left and right.

#### Refer to the following diagram to ensure proper distance from walls and ceiling:




Fig. 3.1

#### Step 2: Attach mounting plate to wall

The mounting plate is the device on which you will mount the indoor unit.

- 1. Remove the screw that attaches the mounting plate to the back of the indoor unit.
- 2. Place the mounting plate against the wall in a location that meets the standards in the **Select Installation Location** step. (See **Mounting Plate Dimensions** for detailed information on mounting plate sizes.)
- 3. Drill holes for mounting screws in places that:
  - have studs and can support the weight of the unit
  - correspond to screw holes in the mounting plate
- 4. Secure the mounting plate to the wall with the screws provided.
- 5. Make sure that mounting plate is flat against the wall.

#### NOTE FOR CONCRETE OR BRICK WALLS:

If the wall is made of brick, concrete, or similar material, drill 5mm-diameter (0.2in-diameter) holes in the wall and insert the sleeve anchors provided. Then secure the mounting plate to the wall by tightening the screws directly into the clip anchors.

#### Step 3: Drill wall hole for connective piping

You must drill a hole in the wall for refrigerant piping, the drainage pipe, and the signal cable that will connect the indoor and outdoor units.

- 1. Determine the location of the wall hole based on the position of the mounting plate. Refer to **Mounting Plate Dimensions** on the next page to help you determine the optimal position. The wall hole should have a 2.5 in (65mm) diameter at least, and at a slightly lower angle to facilitate drainage.
- Using a 65mm (2.5in) or 90mm (3.54in) (depending on models) core drill, drill a hole in the wall. Make sure that the hole is drilled at a slight downward angle, so that the outdoor end of the hole is lower than the indoor end by about 0.2 0.3 in (5 to 7 mm). This will ensure proper water drainage. (See Fig. 3.2)
- 3. Place the protective wall cuff in the hole. This protects the edges of the hole and will help seal it when you finish the installation process.



#### **CAUTION**

When drilling the wall hole, make sure to avoid wires, plumbing, and other potentially harmful materials.

#### MOUNTING PLATE DIMENSIONS






Fig. 3.2


Different models have different mounting plates. In order to ensure that you have ample room to mount the indoor unit, the diagrams to the right show different types of mounting plates along with the following dimensions:


- Width of mounting plate
- Height of mounting plate
- Width of indoor unit relative to plate
- Height of indoor unit relative to plate
- Recommended position of wall hole (both to the left and right of mounting plate)
- Relative distances between screw holes


#### Correct orientation of Mounting Plate











**NOTE:** When the gas side connective pipe is  $\Phi$  5/8 in (16mm) or more, the wall hole should be 3.54 in (90mm).

#### Step 4: Prepare refrigerant piping

The refrigerant piping is inside an insulating sleeve attached to the back of the unit. Prepare the piping before passing it through the hole in the wall. Refer to the **Refrigerant Piping Connection** section of this manual for detailed instructions on 45° pipe flaring and flare torque requirements, technique, etc.

- 1. Based on the position of the wall hole relative to the mounting plate, choose the side from which the piping will exit the unit.
- 2. If the wall hole is behind the unit, keep the knock-out panel in place. If the wall hole is to the side of the indoor unit, remove the plastic knock-out panel from that side of the unit. (See Fig. 3.3). This will create a slot through which your piping can exit the unit. Use needle nose pliers if the plastic panel is too difficult to remove by hand.




Fig. 3.3


- 3. Use scissors to cut down the length of the insulating sleeve to reveal about 6 in (15cm) of the refrigerant piping. This serves two purposes:
  - To facilitate the Refrigerant Piping Connection process
  - To facilitate Gas Leak Checks and enable you to check for dents
- 4. If existing connective piping is already embedded in the wall, proceed directly to the **Connect Drain Hose** step. If there is no embedded piping, connect the indoor unit's refrigerant piping to the connective piping that will join the indoor and outdoor units. Refer to the **Refrigerant Piping Connection** section of this manual for detailed instructions.
- 3. Based on the position of the wall hole relative to the mounting plate, determine the necessary angle of your piping.
- 4. Grip the refrigerant piping at the base of the bend.
- 5. Slowly, with even pressure, bend the piping towards the hole. **Do not** dent or damage the piping during the process.

#### **NOTE ON PIPING ANGLE**

Refrigerant piping can exit the indoor unit from four different angles:

- Left-hand side
- Left rear
- Right-hand side
- Right rear

Refer to Fig. 3.4 for details.





Be extremely careful not to dent or damage the piping while bending them away from the unit. Any dents in the piping will affect the unit's performance.

#### Step 5: Connect drain hose

By default, the drain hose is attached to the lefthand side of unit (when you're facing the back of the unit). However, it can also be attached to the right-hand side.

- 1. To ensure proper drainage, attach the drain hose on the same side that your refrigerant piping exits the unit.
- 2. Attach drain hose extension (purchased separately) to the end of drain hose.
- 3. Wrap the connection point firmly with Teflon tape to ensure a good seal and to prevent leaks.
- 4. For the portion of the drain hose that will remain indoors, wrap it with foam pipe insulation to prevent condensation.
- 5. Remove the air filter and pour a small amount of water into the drain pan to make sure that water flows from the unit smoothly.


# NOTE ON DRAIN HOSE PLACEMENT

Make sure to arrange the drain hose according to **Fig. 3.5**.

- **DO NOT** kink the drain hose.
- **DO NOT** create a water trap.
- O DO NOT put the end of drain hose in water or a container that will collect water.

#### PLUG THE UNUSED DRAIN HOLE

To prevent unwanted leaks you must plug the unused drain hole with the rubber plug provided.





Kinks in the drain hose will create water traps.





Fig. 3.6



#### NOT CORRECT

Fig. 3.7

Do not place the end of the drain hose in water or in containers that collect water. This will prevent proper drainage.




Fig. 3.8



#### **CAUTION** BEFORE PERFORMING ELECTRICAL WORK, READ THESE REGULATIONS

- 1. All wiring must comply with local and national electrical codes, and must be installed by a licensed electrician.
- 2. All electrical connections must be made according to the Electrical Connection Diagram located on the panels of the indoor and outdoor units.
- 3. If there is a serious safety issue with the power supply, stop work immediately. Explain your reasoning to the client, and refuse to install the unit until the safety issue is properly resolved.
- 4. Power voltage should be within 90-110% of rated voltage. Insufficient power supply can cause malfunction, electrical shock, or fire.
- 5. If connecting power to fixed wiring, install a surge protector and main power switch with a capacity of 1.5 times the maximum current of the unit.
- 6. If connecting power to fixed wiring, a switch or circuit breaker that disconnects all poles (except unit ground) and has a contact separation of at least 1/8in (3mm) must be incorporated in the fixed wiring. The qualified technician must use an approved circuit breaker or switch.
- 7. Only connect the unit to an individual branch circuit outlet. Do not connect another appliance to that outlet.
- 8. Make sure to properly ground the air conditioner at all times.
- 9. Every wire must be firmly connected. Loose wiring can cause the terminal to overheat, resulting in product malfunction and possible fire.
- 10. Do not let wires touch or rest against refrigerant tubing, the compressor, or any moving parts within the unit.
- 11. If the unit has an auxiliary electric heater, it must be installed at least 1 meter (40in) away from any combustible materials.



#### **WARNING**

BEFORE PERFORMING ANY ELECTRICAL OR WIRING WORK, TURN OFF THE MAIN POWER TO THE SYSTEM.

#### **Step 6: Connect signal cable**

The signal cable enables communication between the indoor and outdoor units. You must first choose the right cable size before preparing it for connection.

#### **Cable Types**

• **Indoor Power Cable** (if applicable): H05VV-F or H05V2V2-F

• Outdoor Power Cable: H07RN-F

• Signal Cable: H07RN-F

• To Indoor Units: 14/3

### Minimum Cross-Sectional Area of Power and Signal Cables

Appliance Amps (A)	AWG
18	14
25	12
30	10

#### **Other Regions**

Rated Current of Appliance (A)	Nominal Cross-Sectional Area (mm²)
> 3 and ≤ 6	0.75
> 6 and ≤ 10	1
> 10 and ≤ 16	1.5
> 16 and ≤ 25	2.5
> 25 and ≤ 32	4
> 32 and ≤ 40	6

#### CHOOSE THE RIGHT CABLE SIZE

The size of the power supply cable, signal cable, fuse, and switch needed is determined by the maximum current of the unit. The maximum current is indicated on the nameplate located on the side panel of the unit. Refer to this nameplate to choose the right cable, fuse, or switch.

#### TAKE NOTE OF FUSE SPECIFICATIONS


The air conditioner's circuit board (PCB) is designed with a fuse to provide overcurrent protection. The specifications of the fuse are printed on the circuit board, such as: T3.15A/250VAC, T5A/250VAC, etc.

- 1. Prepare the cable for connection:
  - a. Using wire strippers, strip the rubber jacket from both ends of signal cable to reveal about 1.57 in (40mm) of the wires inside.
  - b. Strip the insulation from the ends of the wires.
  - c. Using wire crimper, crimp u-type lugs on the ends of the wires.

#### PAY ATTENTION TO LIVE WIRE

While crimping wires, make sure you clearly distinguish the Live ("L") Wire from other wires.

- 2. Open front panel of the indoor unit.
- 3. Using a screwdriver, open the wire box cover on the right side of the unit. This will reveal



The Wiring Diagram is located on the inside of the indoor unit's wire cover.

### A

#### **WARNING**

INSTALL ALL WIRING PER AUTHORITY HAVING JURISDICTION AND WIRING DIAGRAM LOCATED ON THE INSIDE COVER OF THE INDOOR UNIT'S WIRE COVER.

- 4. Unscrew the cable clamp below the terminal block and place it to the side.
- 5. Facing the back of the unit, remove the plastic panel on the bottom left-hand side.

- 6. Feed the signal wire through this slot, from the back of the unit to the front.
- 7. Facing the front of the unit, match the wire colors with the labels on the terminal block, connect the u-lug and and firmly screw each wire to its corresponding terminal.

#### **IMPORTANT!**

#### DO NOT MIX UP LIVE AND NULL WIRES

This is dangerous, and can cause the air conditioning unit to malfunction.

- 8. After checking to make sure every connection is secure, use the cable clamp to fasten the signal cable to the unit. Screw the cable clamp down tightly.
- 9. Replace the wire cover on the front of the unit, and the plastic panel on the back.


#### **NOTE ABOUT WIRING**

# THE WIRING CONNECTION PROCESS MAY DIFFER SLIGHTLY BETWEEN UNITS.

#### Step 7: Wrap piping and cables

Before passing the piping, drain hose, and the signal cable through the wall hole, you must bundle them together to save space, protect them, and insulate them.

1. Bundle the drain hose, refrigerant pipes, and signal cable according to **Fig. 3.10.** 



#### DRAIN HOSE MUST BE ON BOTTOM

Make sure that the drain hose is at the bottom of the bundle. Putting the drain hose at the top of the bundle can cause the drain pan to overflow, which can lead to fire or water damage.

# DO NOT INTERTWINE SIGNAL CABLE WITH OTHER WIRES

While bundling these items together, do not intertwine or cross the signal cable with any other wiring.

- 2. Using adhesive vinyl tape, attach the drain hose to the underside of the refrigerant pipes.
- 3. Using insulation tape, wrap the signal wire, refrigerant pipes, and drain hose tightly together. Double-check that all items are bundled in accordance with **Fig. 3.10.**

#### DO NOT WRAP ENDS OF PIPING

When wrapping the bundle, keep the ends of the piping unwrapped. You need to access them to test for leaks at the end of the installation process (refer to **Electrical Checks and Leak Checks** section of this manual).

#### **Step 8: Mount indoor unit**

If you installed new connective piping to the outdoor unit, do the following:

- 1. If you have already passed the refrigerant piping through the hole in the wall, proceed to Step 4.
- 2. Otherwise, double-check that the ends of the refrigerant pipes are sealed to prevent dirt or foreign materials from entering the pipes.
- 3. Slowly pass the wrapped bundle of refrigerant pipes, drain hose, and signal wire through the hole in the wall.
- 4. Hook the top of the indoor unit on the upper hook of the mounting plate.
- 5. Check that unit is hooked firmly on mounting by applying slight pressure to the left and right-hand sides of the unit. The unit should not jiggle or shift.
- 6. Using even pressure, push down on the bottom half of the unit. Keep pushing down until the unit snaps onto the hooks along the bottom of the mounting plate.
- 7. Again, check that the unit is firmly mounted by applying slight pressure to the left and the right-hand sides of the unit.

# If refrigerant piping is already embedded in the wall, do the following:

- 1. Hook the top of the indoor unit on the upper hook of the mounting plate.
- 2. Use a bracket or wedge to prop up the unit, giving you enough room to connect the refrigerant piping, signal cable, and drain hose. Refer to **Fig. 3.11** for an example.




Fig. 3.11

- 3. Connect drain hose and refrigerant piping (refer to **Refrigerant Piping Connection** section of this manual for instructions).
- Keep pipe connection point exposed to perform the leak test (refer to Electrical Checks and Leak Checks section of this manual).
- 5. After the leak test, wrap the connection point with insulation tape.
- 6. Remove the bracket or wedge that is propping up the unit.
- 7. Using even pressure, push down on the bottom half of the unit. Keep pushing down until the unit snaps onto the hooks along the bottom of the mounting plate.

#### **DOUBLE-CHECK PIPE CONNECTIONS**

During operation, the pressure of the refrigerant circuit will increase. This may reveal leaks that were not present during your initial leak check. Take time during the Test Run to double-check that all refrigerant pipe connection points do not have leaks. Refer to **Gas Leak Check** section for instructions.

- 5. After the Test Run is successfully completed, and you confirm that all checks points in List of Checks to Perform have PASSED, do the following:
  - a. Using remote control, return unit to normal operating temperature.
  - b. Using insulation tape, wrap the indoor refrigerant pipe connections that you left uncovered during the indoor unit installation process.



You can't use the remote controller to turn on the COOL function when the ambient temperature is below 63°F (17°C). In this instance, you can use the **MANUAL CONTROL** button to test the COOL function.

- 1. Lift the front panel of the indoor unit, and raise it until it clicks in place.
- 2. The **MANUAL CONTROL** button is located on the right-hand side of the unit. Press it 2 times to select the COOL function. See **Fig.8.1**
- 3. Perform Test Run as normal.




Fig. 8.1

# **Disposal Guidelines**

This appliance contains refrigerant and other potentially hazardous materials. When disposing of this appliance, the law requires special collection and treatment. **<u>Do not</u>** dispose of this product as household waste or unsorted municipal waste.

When disposing of this appliance, you have the following options:

- Dispose of the appliance at designated municipal electronic waste collection facility.
- Sell the appliance to certified scrap metal dealers.

#### **Special notice**

Disposing of this appliance in the forest or other natural surroundings endangers your health and is bad for the environment. Hazardous substances may leak into the ground water and enter the food chain.



			Deluxe Wall	Deluxe Wall	Deluxe Wall	Deluxe Wall
Indoor Model		DHWAL09DA	DHWAL12DA	DHWAL18DA	DHWAL24DA	
Power supply		Ph-V-Hz	208-230V~60Hz ,1Ph	208-230V~60Hz ,1Ph	1Ph, 208-230V~60Hz	1Ph, 208-230V~60Hz
	Input	W	50	50	58	72
	Output	W	20	20	58	60
	RLA	Α	0.036	0.036	0.4	0.23
Indoor air flow (Hi/Mi/Lo)		m3/h	628/445/333	631/466/366	901/697/501	1180/1060/824
Indoor air flow (Hi/Mi/Lo)		cfm	370/268/196	371/274/198	530/410/295	695/624/485
Indoor noise	elevel (Hi/Mi/Lo)	dB(A)	41.7/33.4/26.5	45.1/35.8/28.6	46.2/36.3/30.9	51.7/44.5/35.1
	Dimension(W*D*H)	mm	835x198x280	835x198x280	990x218x315	1186x258x343
	Dimension(W*D*H)	inch	32.87x7.80x11.02	32.87x7.80x11.02	38.98x8.58x12.40	46.69x10.16x13.39
Indoor unit	Packing (W*D*H)	mm	910x270x355	910x270x355	1065x300x400	1265x420x340
muoor unit	Packing (W*D*H)	inch	35.83x10.63x13.98	35.83x10.63x13.98	41.93x11.81x15.75	49.80x16.53x13.39
	Net/Gross weight	kg	9.0/11.5	9.0/12.1	12.2/15.8	18.1/24.3
	Net/Gross weight	lbs.	19.8/25.4	19.8/26.7	26.9/34.8	39.9/53.6
Thermostat type			Remote Control	Remote Control	Remote Control	Remote Control
Thermostat	Indoor(cooling/ hea	°C	17~32/0~30	17~32/0~30	17~32/0~30	17~32/0~30
Setting Range	Indoor(cooling/ hea	°F	62~90/32~86	62~90/32~86	62~90/32~86	62~90/32~86



Tel. 800 253 7900 www.ecrinternational.com All specifications subject to change without notice. ©2018 ECR International, Inc.